

HS-6011

Pentium®-II-III-Celeron? BX L/VGA LAN

PICMG Bus Full Size All-in-one CRT/Panel RS-232/422/485
DMA33 WDT DOC USB IrDA LAN PC/104 CTA
100MHz Bus Pentium®-II-III-Celeron? CPU at Face-Side

HS-6011V

Pentium®-II-III-Celeron? BX L/VGA

PICMG Bus Full Size All-in-one CRT/Panel RS-232/422/485
DMA33 WDT DOC USB IrDA PC/104 CTA
100MHz Bus Pentium®-II-III-Celeron? CPU at Face-Side

HS-6011L

Pentium®-II-III-Celeron? BX LAN

PICMG Bus Full Size All-in-one RS-232/422/485
DMA33 WDT DOC USB IrDA LAN PC/104 CTA
100MHz Bus Pentium®-II-III-Celeron? CPU at Face-Side

HS-6011P

Pentium®-II-III-Celeron? BX ISB

PICMG Bus Full Size All-in-one RS-232/422/485
DMA33 WDT DOC USB IrDA PC/104 CTA
100MHz Bus Pentium®-II-III-Celeron? CPU at Face-Side

Copyrights

This manual is copyrighted and all rights are reserved. It is not allow any non authorization in copied, photocopied, translated or reproduced to any electronic or machine readable form in whole or in part without prior written consent from the manufacturer.

In general, the manufacturer will not be liable for any direct, indirect, special, incidental or consequential damages arising from the use of inability to use the product or documentation, even if advised of the possibility of such damages.

The manufacturer keeps the rights in the subject to change the contents of this manual without prior notices in order to improve the function design, performance, quality and reliability. The author assumes no responsibility for any errors or omissions, which may appear in this manual, nor does it make a commitment to update the information contained herein.

Trademarks

BOSER is registered trademark of BOSER Technology Co., Ltd.

ISB is registered trademark of BOSER Technology Co., Ltd.

Intel is a registered trademark of Intel Corporation.

Award is a registered trademark of Award International Inc.

All other trademarks, products and or product's name mentioned herein are mentioned for identification purposes only, and may be trademarks and/or registered trademarks of their respective companies or owners.

©Copyright 1999

All Rights Reserved.

User Manual edition 1.7, Aug.24 2001

Contents

<i>HS-6011</i>	1
<i>HS-6011V</i>	1
<i>HS-6011L</i>	1
<i>HS-6011P</i>	1
GENERAL INFORMATION	3
1.1 MAJOR FEATURES.....	4
1.2 SPECIFICATIONS	5
1.3 DELIVERY PACKAGE.....	7
HARDWARE INSTALLATION	8
2.1 CAUTION OF STATIC ELECTRICITY	8
2.2 CAUTION ON UNPACKING AND BEFORE INSTALLATION.....	9
2.3 HS-6011'S LAYOUT	10
2.4 QUICK LISTING OF JUMPERS.....	11
2.5 QUICK LISTING OF CONNECTORS	12
2.6 JUMPER SETTING DESCRIPTION.....	14
2.7 SETTING THE BUS-CLOCK FREQUENCY	15
2.8 FREQUENCY MULTIPLIER SETTING	16
2.9 SETTING THE RTC CONFIGURATION.....	17
2.10 SYSTEM MEMORY DRAM	17
2.11 ATX/AT POWER SELECT	17
2.12 WATCH-DOG TIMER	18
2.13 PCI VGA CONTROLLER	21
2.14 DISKONCHIP? ADDRESS SETTING	21
2.15 LCD 3.3/5.0V POWER SELECT	22
2.16 MANUFACTURER'S DEFAULT SETTING.....	22
2.17 TEMPERATURE ALARM	22
2.18 RETENTION MECHANISM.....	23
CONNECTION	24
3.1 POWER AND FAN CONNECTORS	24
3.2 IDE'S LED, KEY-LOCK AND RESET BUTTON	25
3.3 EXTRA SPEAKER CONNECTOR.....	25
3.4 PCI E-IDE DRIVE CONNECTOR.....	27

3.5 PS/2 POWER ON/OFF CONTROL.....	29
3.6 PARALLEL PORT CONNECTOR.....	29
3.7 THE FLOPPY DISK DRIVE CONNECTOR.....	30
3.8 SERIAL PORTS CONNECTORS.....	31
3.9 KEYBOARD CONNECTORS.....	33
3.10 PS/2 MOUSE 6-PIN MINI-DIN CONNECTOR.....	33
3.11 VGA-CRT CONNECTOR.....	34
3.12 FLAT-PANEL CONNECTOR.....	35
3.13 IR CONNECTOR.....	37
3.14 USB PORT CONNECTOR.....	37
3.15 PC/104 BUS CONNECTION.....	38
3.16 FAST ETHERNET CONNECTOR.....	40
3.17 ATX POWER CONTROLLER CONNECTOR.....	41
AWARD BIOS SETUP.....	42
4.1 MAIN MENU.....	43
4.2 STANDARD CMOS SETUP.....	44
4.3 BIOS FEATURES SETUP.....	45
4.4 CHIPSET FEATURES SETUP.....	46
4.5 INTEGRATED PERIPHERALS.....	47
4.6 POWER MANAGEMENT SETUP.....	48

Chapter-1

General Information

The HS-6011 is a bus-100MHz Intel® BX chipset design PICMG bus Pentium®II-III-Celeron? Industrial Single Board (I.S.B.) CPU card with features combine together to make it an ideal all-in-one industrial single board computer, enhanced I/O effects with VGA interface supports LCD Display panel and CRT Monitor on-board.

The HS-6011 also provides one set of PC/104 bus for 8/16-bit industrial application with based on PC/104 standard bus.

With onboard DMA33 of mode 4 to IDE drive interface architecture, the HS-6011 supports with maximum 33.3 MB/sec in data transfer rating to 4 pieces IDE drive connection. Design with Intel® 82443BX and 82371EB core logic chipset, the HS-6011 supports all series Pentium®II-III-Celeron? operating at 233 ~ 650MHz. The on-board C&T® 69000 VGA chipset supports up to 1280 x 1024 256 colors display resolution with on-chip 2MBytes memory, and it provides both VGA CRT Monitor and LCD Panel display connection.

The advanced PICMG bus add-on connection of HS-6011 allows user could easily obtain both ISA's 16-bit and PCI's 32-bit full set signals from a full size PICMG slot for suitable plug into system with 8/16/32-bit ISA and-or PCI slots operating. The HS-6011 provides with two pieces 168-pin DIMM sockets support up to 1.0GBytes of main system memory.

A single Flash chip holds the system BIOS, and you can easy update the Flash BIOS by the Utility Update. Advanced USB and IR ports also provide for faster and easily in data transmission. You can also use the DOS version of the "DiskOnChip? " socket by issuing commands from the DOS prompt without the necessity of other software supports up to 144MB.

If a non-expect program cause halts, the onboard WDT Watch-Dog Timer will automatically reset the CPU or generate an interrupt. The watchdog is designed with hardware only and doesn' t need any arithmetical functions of a real-time clock chip. This ensures the reliability in an unmanned or standalone system.

1.1 Major Features

- ☞ One axial-horizontal type Slot-1 socket at face-side for Intel® Pentium® II-III-Celeron? 233 650 MHz Processors.
- ☞ Intel® 82443 BX chipset.
- ☞ PICMG add-on bus with on-board PC/104 bus connector for 8/16-bit supported.
- ☞ Two pieces DIMM sockets supports DRAM up to 1.0 GB.
- ☞ Two fast PCI DMA33-IDE connector support four IDE drives include large size hard disks, CD-ROM, tape backup etc.
- ☞ PnP I/O address & IRQ selection.
- ☞ Two high-speed RS-232 serial ports support 16C550 UART with 16-byte FIFO. One port provides RS-422/485 selection.
- ☞ One enhanced bi-directional parallel port, supports SPP/EPP/ECP.
- ☞ On board PS/2 Keyboard and PS/2 Mouse connector.
- ☞ On board W83977 super I/O.
- ☞ On-board C&T® 69000 SVGA adapter with on-chip 2MBytes memory supports VGA LCD Panel and CRT Monitor display.
- ☞ On board Intel® 82558 100-Based Network.
- ☞ “DiskOnChip™” Socket supported memory size up to 72 MB.
- ☞ On-board two USB ports and one IrDA port.
- ☞ Build-in one industrial WDT Watch-Dog-Timer.
- ☞ AWARD Y2K PnP Flash BIOS.
- ☞ Hardware Temperature Alarm

*It will be a Warning “beep” come out if the CPU' s temperature reached 60 . And it will stop as the CPU' s temperature going down below 60 again.

1.2 Specifications

- ✎ **CPU:** One piece Intel® Pentium®II-III-Celeron? 233/ 266/ 300/ 333/ 400/450/500/650MHz.
- ✎ **Bus interface:** PICMG bus, comply with ISA and PCI slot One on-board PC/104 bus connector.
- ✎ **Chipset:** Intel® 82443 BX bus-100MHz chipset.
- ✎ **Data bus:** 64-bit
- ✎ **Processing ability:** 64-bit
- ✎ **C&T® VGA Controller:** C&T® 69000 VGA, on-chip 2 MB memory included, supports up to 1280x1024 256 colors VGA modes resolution. Also provides one 50-pin LCD Panel connector, one internal 10-pin VGA-CRT connector.
- ✎ **PCI Enhanced IDE Interfaces:** Total four IDE drives supports with Mode 3 & 4 DMA33 function provides transfer rate up to 33.3MB/sec.
- ✎ **RAM memory:** Two pieces 168-pin DIMM sockets supports up to 1.0 GBytes.
- ✎ **Cache memory:** Slot-1 socket supports Intel's Pentium®II-III-Celeron? CPU with build-in 512KB Pipeline burst cache memory.
- ✎ **Floppy disk drive interface:** Supports up to two floppy disk drives.
- ✎ **LAN:** Intel® 82558 supports 100-Based.
- ✎ **Parallel port:** Supports SPP/ECP/EPP.
- ✎ **Serial ports:** Two RS-232 ports with 16-byte FIFO 16C550 UART. One port provides RS-422/485 selection.
- ✎ **BIOS:** AWARD Y2K PnP Flash BIOS.
- ✎ **WDT Watchdog timer:** Periods set 1, 2, 10, 20 , 110 or 220 seconds, activity trigger with Reset or NMI.
- ✎ **DMA channels:** 7

-
- ✍ ✍ **Temperature Alarm:** Hardware monitoring.
 - ✍ ✍ **Interrupt levels:** 15
 - ✍ ✍ **Keyboard:** 6-pin mini-DIN connector or 5-pin header.
 - ✍ ✍ **Mouse:** 6-pin mini-DIN connector support PS/2 type mouse.
 - ✍ ✍ **USB:** Supports 2 USB header.
 - ✍ ✍ **IR interface:** Supports one IrDA TX/RX header.
 - ✍ ✍ **Flash memory Disk:** Socket for DiskOnChip™ (DOC).
 - ✍ ✍ **Fuse:** Automatically resumes polyswitch resettable fuse.
 - ✍ ✍ **Extra Power:** Provides one 4-PIN extra DC +5V/+12V power connector.
 - ✍ ✍ **CMOS:** DS12B887 or equivalent device.
 - ✍ ✍ **Power voltage requested:** +5V, +12V and -12V.
 - ✍ ✍ **Maximum Power Consumption:** +5V@5A(350MHz PII),
+12V@20mA,
-12V@20mA.
 - ✍ ✍ **Operating temperature:** 0-55°C (CPU need cooler).
 - ✍ ✍ **Board size:** 7.3"(L) x 4.8" (W) (185mm x 122mm).

The HS-6011 provides with VGA Interface to LCD and Monitor, IDE-DMA33, WDT, DOC, USB, IrDA and LAN etc.

The HS-6011V provides with all function but without LAN.

The HS-6011L provides with all function but without VGA.

The HS-6011P provides with all function but without VGA and without LAN.

1.3 Delivery Package

The delivery package of HS-6011 includes all following items:

- ~~///~~ One HS-6011 Industrial Single Board
- ~~///~~ One Printer Port Bracketed Flat Cable
- ~~///~~ One COM Port Bracketed Flat Cable
- ~~///~~ Two IDE port Flat Cable
- ~~///~~ One FDD port Flat Cable
- ~~///~~ One PS/2 to Standard DIN type Keyboard Transfer Cable
- ~~///~~ Utility Diskette
- ~~///~~ User' s Manual
- ~~///~~ 5 pin ATX Power Connector Cable

Please contact with your dealer if any of these items are missing or damaged when purchasing. And please keep all parts of the delivery package with packing materials in case of you want to ship or store the product in future.

Chapter-2

Hardware Installation

This chapter provides the information on how to install the hardware of HS-6011. At first, please follow up sections 1.3, 2.1 and 2.2 in check the delivery package and carefully unpacking. Following after, the jumpers setting of switch, watchdog timer and the DiskOnChip? address selection etc.

2.1 Caution of Static Electricity

The HS-6011 has been well package with an anti-static bag in protect its sensitive computer components and circuitry from the damage of static electric discharge.

Note: DO NOT TOUCH THE BOARD OR ANY OTHER SENSITIVE COMPONENTS WITHOUT ALL NECESSARY ANTI-STATIC PROTECTION.

You should follow the steps as following to protect the board in against the static electric discharge whenever you handle the board:


1. Please use a grounding wrist strap on whoever needs to handle the HS-6011. Well clip the ALLIGATOR clip of the strap to the end of the shielded wire lead from a grounded object. Please put on and connect the strap before handle the HS-6011 for harmlessly discharge any static electricity through the strap.
2. Please use anti-static pad for put any components or parts or tools on the pad whenever you work on them outside the computer. You may also in use the anti-static bag instead the pad. Please ask from your local supplier in help up your necessary parts on anti-static requirement.

2.2 Caution on Unpacking and Before Installation

First of all, please follow with all necessary steps of section 2.1 in protection the HS-6011 from electricity discharge. With refer to section 1.3, please check the delivery package again with following steps:

1. Unpacking the HS-6011, keep well storage of all packing material, manual and diskette etc. if has.
2. Is there any components lose or drop from the board? **DO NOT INSTALL IF HAPPENED.**
3. Is there any visual damaged of the board? **DO NOT INSTALL IF HAPPENED.**
4. Well check from your optional parts (i.e. CPU, SRAM, DRAM, ROM-Disk etc.) for completed setting all necessary jumpers setting to jumper pin-set and CMOS setup correctly. Please also reference to all information of jumpers setting in this manual.
5. Well check from your external devices (i.e. Add-On-Card, Driver Type etc.) for completed add-in or connection and CMOS setup correctly. Please also reference to all information of connector connection in this manual.
6. Please keep all necessary manual and diskette in a good condition for your necessary re-installation if you change your Operating System or whatever needs.

2.3 HS-6011's Layout



2.4 Quick Listing of Jumpers

JP2 (1-2 OFF)	— Bus-Clock 66/100MHz Select
JP3 (1-2 OFF)	— Manufacturer' s Default Setting
JP4 (2-3 ON)	— LCD 3.3/5.0V Power Select
JP5 (1-2, 7-8 ON)	— Frequency Multiplier Select
JP6 (1-2 ON)	— AT/ATX Power Select
JP7 (1-2 OFF)	— Temperature Alarm
JP8 (1-2 ON)	— RS-232/422/485 Select
JP9 (1-2 ON)	— RS-232/422/485 Select
JP10 (1-2, 3-4 ON)	— DiskOnChip™ Address setting
JP10 (5-6, 7-8, 9-10 ON)	—WDT Time Scaling Select
JP11 (3-5, 4-6 ON)	— RS-232/422/485 Select
JP12 (3-5, 4-6 ON)	— RS-232/422/485 Select
JP13 (1-2 OFF)	— RTC Clear Jumper
JP14 (2-3 ON)	— WDT Activity Select

2.5 Quick Listing of Connectors

JP1: RESET PIN
BZ1: ON-BOARD BUZZER
D4: ON-BOARD POWER-ON LED INDICATOR
D1, D2, D3: INTERNAL LAN' S LED INDICATORS
CN1: KEYLOCK CONNECTOR
CN2: SPEAKER CONNECTOR
CN3: HDD LED CONNECTOR
CN4: INTERNAL FAN' S POWER CONNECTOR FOR CPU
CN5: ATX POWER ON/OFF SWITCH
CN6: INTERNAL 5-PIN KEYBOARD CONNECTOR
CN7: POWER 4-PIN CONNECTOR
CN8: 1st IDE CONNECTOR
CN9: 2nd IDE CONNECTOR
CN10: INTERNAL VGA LCD CONNECTOR (HEADER 25x2)
CN11: ATX POWER CONTROL
CN12: PARALLEL PORT CONNECTOR
CN13: INTERNAL COM-2 RS-422/485 CONNECTOR (HEADER 5X2)
CN14: PC104-BUS 64-PIN ISA 8-BIT
CN15: PC104-BUS 40-PIN ISA 16-BIT
CN16: FDD CONNECTOR
CN17: INTERNAL COM-1 RS-232 CONNECTOR (HEADER 5X2)
CN18: INTERNAL COM-2 RS-232 CONNECTOR (HEADER 5X2)
CN19: INTERNAL VGA MONITOR CONNECTOR (HEADER 5X2)
CN20: USB PORTS CONNECTOR
CN21: IR CONNECTOR (6-PIN)
CN22: RJ-45 10/100-BASED LAN CONNECTOR
CN23: EXTERNAL COM-1 RS-232 CONNECTOR (DB9)
CN24: EXTERNAL MINI-DIN PS/2 MOUSE CONNECTOR
CN25: EXTERNAL VGA CONNECTOR (DB15)
CN26: EXTERNAL COM-2 RS-232 CONNECTOR (DB9)
CN27: EXTERNAL MINI-DIN PS/2 KEYBOARD CONNECTOR
DM1: DIMM SOCKET 0
DM2: DIMM SOCKET 1

SLOT-1: PENTIUM™-II-III-Celeron? PROCESSOR' S SOCKET

U24: DiskOnChip™ SOCKET

LE1~LE3: LAN LED CONNECTOR

2.6 Jumper Setting Description

A jumper pin-set is **ON** as a shorted circuit with a plastic cap inserted over two pins. A jumper pin-set is **OFF** as an open circuit with a plastic cap inserted over one or no pin(s) between pins. The below figure 2.2 shows the examples of different jumper pin-set setting as **ON** or **OFF** in this manual.




Figure 2.2

All jumper pin-set already has its default setting with the plastic cap inserted as ON, or without the plastic cap inserted as OFF. The default setting may reference in this manual with a " * " symbol in front of the selected item.

2.7 Setting the Bus-Clock Frequency

The HS-6011 provides all necessary by jumper setting in using Bus-Clock frequency as the system bus clocking with JP2 setting as following:

/// **Bus-Clock Frequency Setting of JP2:**

Bus-Clock Frequency	JP2
* 100MHz	OFF
66MHz	ON

2.8 Frequency Multiplier Setting

The HS-6011 provides JP5 for define the selection of the Frequency Multiplier value of system bus to processor core in following table:

2.8 **Frequency Multiplier Setting of JP5:**

Frequency Multiplier:					System Clock	
System Bus to Processor Core	7-8	5-6	3-4	1-2	JP5 ON	JP5 OFF
					66	* 100
3x	ON	ON	OFF	ON	200	300
4x	ON	ON	ON	OFF	266	400
5x	ON	ON	OFF	OFF	333	500
2.5x	ON	OFF	ON	ON	166	250
* 3.5x	ON	OFF	OFF	ON	233	* 350
4.5x	ON	OFF	ON	OFF	300	450
5.5x	OFF	ON	OFF	OFF	366	550
6x	ON	OFF	ON	ON	400	600
6.5x	OFF	OFF	ON	ON	430	650
7x	ON	OFF	OFF	ON	460	700
7.5x	OFF	OFF	OFF	ON	500	750
8x	ON	OFF	ON	OFF	530	800

The bus-clock is setting by JP2 and JP5 The default setting is for Intel Pentium®II 350MHz processor. If the bus Frequency not match processor frequency, the system will be unstable.

2.9 Setting the RTC Configuration

The HS-6011 provides a setting for the selection of the RTC Clear Jumper by JP13 setting as following:

LL **CMOS Setting of JP13:**

CMOS Clear Jumper	JP13
Normal	* OFF
Clear CMOS	ON

2.10 System Memory DRAM

The HS-6011 provides a wide range on-board DRAM memory by two pieces DIMM sockets (DIMM-1, DIMM-2) request the access time should meet PC-100 standard.. The maximum capacity of the on board memory is 1.0GBytes.

See the figure on section 2.3 for get the identifying the banks.

2.11 ATX/AT Power Select

The HS-6011 provides a selection by a three-pin jumper JP6 for setting the power supply type in using.

LL **ATX/AT Power Select Setting of JP6:**

Power Supply In Using	JP6
ATX Power Supply	2-3
AT Power Supply	* 1-2

2.12 Watch-Dog Timer

There are three access cycles of Watch-Dog Timer as Enable, Refresh and Disable. The Enable cycle should proceed by READ PORT 443H. The Disable cycle should proceed by READ PORT 045H. A continue Enable cycle after a first Enable cycle means Refresh.

Once if the Enable cycle activity, a Refresh cycle is request before the time-out period for restart counting the WDT Timer's period. Otherwise, it will assume that the program operation is abnormal when the time counting over the period preset of WDT Timer. A System Reset signal to start again or a NMI cycle to the CPU comes if over.

The JP14 is using for select the active function of watch-dog timer in disable the watch-dog timer, or presetting the watch-dog timer activity at the reset trigger, or presetting the watch-dog timer activity at the NMI trigger.

⚡ JP14 : Watch-Dog Active Type Setting

JP14	DESCRIPTION
*2-3	System Reset
1-2	Active NMI
OFF	disable Watch-dog timer

⚡ JP10 (pin 5-6, 7-8, 9-10) : WDT Time - Out Period

PERIOD	WD2	WD1	WD0
	5 – 6	7 – 8	9 – 10
*1 sec	ON	ON	ON
2 sec	OFF	ON	ON
10 sec	ON	OFF	ON
20 sec	OFF	OFF	ON
110 sec	ON	ON	OFF
220 sec	OFF	ON	OFF

The Watch-dog timer is disabled after the system Power-On. The watch-dog timer can be enabled by a Enable cycle with reading the control port (443H), a Refresh cycle with reading the control port (443H) and a Disable cycle by reading the Watch-dog timer disable control port (045H). After a Enable cycle of WDT, user must constantly proceed a Refresh cycle to WDT before its period setting comes ending of every 1, 2, 16 or 256 seconds which pre-setting by JP10 (PIN 5-6, 7-8). If the Refresh cycle does not active before WDT period cycle, the on board WDT architecture will issue a Reset or NMI cycle to the system.

The Watch-Dog Timer is controlled by two I/O ports.

443H	I/O Read	The Enable cycle.
443H	I/O Read	The Refresh cycle.
045H	I/O Read	The Disable cycle.

The following sample programs showing how to Enable, Disable and Refresh the Watch-dog timer:

```

WDT_EN_RF      EQU    0443H
WDT_DIS        EQU    0045H
WT_Enable      PUSH   AX           ; keep AX DX
                PUSH   DX
                MOV    DX,WDT_EN_RF ; enable the watch-dog
timer
                IN     AL,DX
                POP    DX           ; get back AX, DX
                POP    AX
                RET
WT_Rresh       PUSH   AX           ; keep AX, DX
                PUSH   DX
                MOV    DX,WDT_ET_RF ; refresh the watch-dog
timer
                IN     AL,DX
                POP    DX           ; get back AX, DX
                POP    AX
                RET
WT_DISABLE     PUSH   AX
                PUSH   DX

```

```
timer          MOV    DX,WDT_DIS    ; disable the watch-dog
               IN     AL,DX
               POP    DX      ; get back AX, DX
               POP    AX
               RET
```

2.13 PCI VGA Controller

The HS-6011 has built-in a C&T 69000 VGA Controller with on-chip 2 MB memory, support resolutions up to 1280 x 1024 256 colors to VGA-CRT monitor. The HS-6011 also provides one 50-pin internal LCD Panel connector CN10, and reserved internal 10-pin VGA-CRT header connector.

2.14 DiskOnChip? Address Setting

The HS-6011 provides a U24 socket for install the DiskOnChip? module.

A JP10 (pin 1-2, 3-4) may select the starting memory address of the DiskOnChip? (D.O.C.) for avoid the mapping area with any other memory devices. If you have another extra memory devices in the system with the same memory, neither the HS-6011 nor the extra memory devices will function normally. Please setting both at different memory address mapping.

JP10 : DiskOnChip? Address

Memory Address Mapping	JP10 3-4	JP10 1-2
D000	* ON	* ON
D800	ON	OFF
E000	OFF	ON
E800	OFF	OFF

*) : default setting

The D.O.C. function allows the system in using without FDD nor HDD. The D.O.C. may formatting as driver C: or driver A:. User may also easily uses the DOS's commands such as FORMAT, SYS, COPY, XCOPY, DISCOPY and DISKCOMP etc. This is means that the D.O.C. may uses as driver-A if the system without FDD-A for ambient application. Please contact with your supplier for different size D.O.C. module.

2.15 LCD 3.3/5.0v Power Select

The HS-6011 provides a select for using the LCD Panel with 3.3V or 5.0V as setting in the following:

⚡ **LCD Power Select of JP4:**

LCD Power Type	JP4
5.0V	* 2-3
3.3V	1-2

2.16 Manufacturer's Default Setting

The HS-6011 has some jumpers which are for design use only. Please set as the board provides of the manufacturer's default setting in the following:

⚡ **Manufacturer's Default Setting of JP3 :**

Manufacturer's	Setting
JP3	* OFF


2.17 Temperature Alarm

The HS-6011 provides a select for Hardware temperature Alarm. If the CPU's temperature reached $60^{\circ}\text{C}\pm 10\%$, the warning "beep" will be come out. And it will stop as the CPU's temperature going down below $60^{\circ}\text{C}\pm 10\%$ again.

⚡ **Temperature Alarm Default Setting of JP7:**

Temperature Alarm	JP7
Enabled	ON
Disabled	OFF

2.18 Retention Mechanism



For SECC2 PII/III processor types, use the two caps on both ends after installing the processor to secure the installation. SECC types do not require these caps.

Chapter-3

Connection

This chapter gives all necessary information of the peripheral's connections, switches and indicators.

3.1 Power and FAN Connectors

The HS-6011 provides one 4-pin DC-Power connector as following CN7 pin information. And also provides one 3-pin fan out connector at solder side as following CN4 pin information.

✂ CN7 : 4-PIN POWER CONNECTOR

PIN NO.	DESCRIPTION
1	Vcc
2	GND
3	GND
4	+12V

✂ CN4 : 3-PIN FAN IN/OUT CONNECTOR

PIN NO.	Type	DESCRIPTION
1	To FAN	GND
2	To FAN	+12V
3	NC	NC

The output pin-2 (+12V) is a DC power to FAN.

3.2 IDE's LED, Key-Lock and Reset Button

The HS-6011 has one LED (D4) indicates out power-on status. And the following provides the pin information for IDE's LED connector, Key-Lock and Reset Button connections from CN3, CN1 and JP1.

☞ **CN3 : IDE LED connector**

PIN NO.	DESCRIPTION
1	HDD ACTIVE#
2	+5V

☞ **CN1 : POWER LED & KEYLOCK**

PIN NO.	DESCRIPTION
1	POWER LED ANODE
2	NC
3	GROUND
4	KEYLOCK
5	GROUND

☞ **JP1 : RESET BUTTON**

PIN NO.	DESCRIPTION
1	GROUND
2	EXTERNAL RESET

3.3 Extra Speaker Connector

The HS-6011 has an on-board buzzer (BZ1). And it also provides the CN2 in allows user to connecting to the external speaker.

2.6 **CN2 : Speaker Connector**

PIN NO.	DESCRIPTION
1	SPEAKER SIGNAL
2	NC
3	GROUND
4	+5V

3.4 PCI E-IDE Drive Connector

Two standard 40-pin header daisy-chain driver connectors provide as CN8 and CN9 with following pin assignment. Total four IDE (Integrated Device Electronics) drivers may connect.

CN8 (IDE 1) : Primary IDE Connector

☞ CN8 : IDE Interface Connector

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RESET	2	GROUND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GROUND	20	N/C
21	N/C	22	GROUND
23	IOW#	24	GROUND
25	IOR#	26	GROUND
27	N/C	28	BALE - DEFAULT
29	N/C	30	GROUND# -DEFAULT
31	INTERRUPT	32	IOCS16#-DEFAULT
33	SA1	34	N/C
35	SA0	36	SA2
37	HDC CS0	38	HDC CS1#
39	HDD ACTIVE	40	GROUND

CN9 (IDE 2) : Secondary IDE Connector

✂ CN9 : IDE Interface Connector

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RESET	2	GROUND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GROUND	20	N/C
21	N/C	22	GROUND
23	IOW#	24	GROUND
25	IOR#	26	GROUND
27	N/C	28	BALE - DEFAULT
29	N/C	30	GROUND# -DEFAULT
31	INTERRUPT	32	IOCS16#-DEFAULT
33	SA1	34	N/C
35	SA0	36	SA2
37	HDC CS0	38	HDC CS1#
39	HDD ACTIVE	40	GROUND

3.5 PS/2 Power ON/OFF Control

The HS-6011 reserved a CN5 for ATX Power ON/OFF Control.

☞ **CN5 : ATX Power ON/OFF Control**

CN5	DESCRIPTION	
2	Pin 1-2 OFF (LOW)	Pin 1-2 ON (HIGH)
	Remain Power Status	Change Power ON / OFF
1	Standby 3.3V	

3.6 Parallel Port Connector

A standard 26-pin flat cable driver connector provides as CN12 with following pin assignment for connection to parallel printer.

☞ **CN12 : Parallel Port Connector**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	STROBE	2	DATA 0
3	DATA 1	4	DATA 2
5	DATA 3	6	DATA 4
7	DATA 5	8	DATA 6
9	DATA 7	10	ACKNOWLEDGE
11	BUSY	12	PAPER EMPTY
13	PRINTER SELECT	14	AUTO FORM FEED
15	ERROR#	16	INITIINTELZE
17	PRINTER SELECT LN#	18	GROUND
19	GROUND	20	GROUND
21	GROUND	22	GROUND
23	GROUND	24	GROUND
25	GROUND	26	GROUND

3.7 The Floppy Disk Drive Connector

A standard 34-pin header daisy-chain driver connector provides as CN16 with following pin assignment. Total two FDD drivers may connect.

2.6 **CN16 : FDD CONNECTOR**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GROUND	2	REDUCE WRITE
3	GROUND	4	N/C
5	GROUND	6	N/C
7	GROUND	8	INDEX#
9	GROUND	10	MOTOR ENABLE A#
11	GROUND	12	DRIVE SELECT B#
13	GROUND	14	DRIVE SELECT A#
15	GROUND	16	MOTOR ENABLE B#
17	GROUND	18	DIRECTION#
19	GROUND	20	STEP#
21	GROUND	22	WRITE DATA#
23	GROUND	24	WRITE DATA#
25	GROUND	26	TRACK 0#
27	GROUND	28	WRITE PROTECT#
29	GROUND	30	READ DATA#
31	GROUND	32	SIDE 1 SELECT
33	GROUND	34	DISK CHANGE#

3.8 Serial Ports Connectors

According to different configuration, the HS-6011, HS-6011V, HS-6011L and HS-6011P provides with different COM ports assignment.

- ✎ COM-1 RS-232 at external connector CN23 of all models.
- ✎ COM-2 RS-232 at external connector CN26 of HS-6011P.
- ✎ COM-1 RS-232 also at internal connector CN17 of all models.
- ✎ COM-2 RS-232 also at internal connector CN18 of all models.
- ✎ COM-2 RS-422/485 at internal connector CN13 of all models.

All COM ports provides with high speeds NS16C550 compatible UARTs with Read/Receive 16 byte FIFO serial ports. Please see the following pin assignment.

✎ **CN23/26 : RS-232 Serial Port DB-9 Connector (COM1/COM2)**

PIN NO.	DESCRIPTION
1	DATA CARRIER DETECT (DCD)
2	RECEIVE DATA (RXD)
3	TRANSMIT DATA (TXD)
4	DATA TERMINAL READY (DTR)
5	GROUND (GND)
6	DATA SET READY (DSR)
7	REQUEST TO SEND (RTS)
8	CLEAR TO SEND (CTS)
9	RING INDICATOR (RI)

✎ **CN17/18 : RS-232 Serial Port 10-pin Header (COM1/COM2)**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	DCD	2	DSR
3	RXD	4	RTX
5	TXD	6	CTX
7	DTR	8	RI
9	GND	10	NC

☞ **CN13 : RS422/485**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	TX-	2	TX+
3	RX+	4	RX-
5	GND	6	RTS-
7	RTS+	8	CTS+
9	CTS-	10	NC

The table here in show out on how to select and setting the COM-2 as RS-232 as CN26 or CN18, or RS-422/485 at CN13.

Jumper	RS-232	RS-422/485
JP11	3-5, 4-6	1-3, 2-4
JP12	3-5, 4-6	1-3, 2-4
JP8	OPEN	3-4 or 1-2
JP9	OPEN	3-4 or 5-6

☞ **JP8 : Receiver Enable Control**

JP9	DESCRIPTION
1-2 ON	Always Enable
3-4 ON	Enable by writing the REG : 2 EFH BIT1=1
*1-2 OFF	Always Disable

☞ **JP9 : Transceiver Enable Control**

JP9	DESCRIPTION
1-2 ON	Always Enable
3-4 ON	Enable by "-RTS" signal
5-6 ON	Enable by writing the REG : 2 EFH BIT0=1
*1-2 OFF	Always Disable

3.9 Keyboard Connectors

The HS-6011 offers two possibilities for keyboard connections to external PS/2 type keyboard at CN27 and an internal 5-pin header at CN6.

☞ **CN6 : 5-pin Header Keyboard Connector**

PIN NO.	DESCRIPTION
1	KEYBOARD CLOCK
2	KEYBOARD DATA
3	N/C
4	GROUND
5	+5V

☞ **CN27 : 6-pin Mini-DIN Keyboard Connector**

PIN NO.	DESCRIPTION
1	KEYBOARD DATA
2	N/C
3	GROUND
4	+5V
5	KEYBOARD CLOCK
6	N/C

3.10 PS/2 Mouse 6-pin Mini-DIN Connector

The HS-6011 provides an external PS/2 mouse connector at CN24 with following pin information.

☞ **CN24 : PS/2 Mouse Connector**

PIN NO.	DESCRIPTION
1	DATA
2	NC
3	GROUND
4	+5V
5	CLK
6	NC

3.11 VGA-CRT Connector

The HS-6011 provides two possible connectives of VGA-CRT connections. One standard DB-15 external VGA connector as following CN25 pin information. Another internal 10-pin header for VRA-CRT connection as following CN19 pin information.

☞ **CN25 : 15-pin DB-15 Female VGA-CRT connector**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RED	2	GREEN
3	BLUE	4	NC
5	GROUND	6	GROUND
7	GROUND	8	GROUND
9	NC	10	GROUND
11	NC	12	NC
13	HSYNC	14	VSYNC
15	NC		

☞ **CN19 : 10-pin 5x2 Header VGA-CRT connector**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RED	2	GROUND
3	GREEN	4	GROUND
5	BLUE	6	GROUND
7	HSYNC	8	GROUND
9	VSYNC	10	GROUND

3.12 Flat-Panel Connector

The HS-6011 provides a 50-pin 2.0 mm pitch header connector (CN10) for 3.3V or 5V Panel connection with following pin-assignment.

+12V	1	2	+12V
GND	3	4	GND
* +3.3 or +5V PVcc	5	6	ENAVdd
FPVee	7	8	GND
P ₀	9	10	P ₁
P ₂	11	12	P ₃
P ₄	13	14	P ₅
P ₆	15	16	P ₇
P ₈	17	18	P ₉
P ₁₀	19	20	P ₁₁
P ₁₂	21	22	P ₁₃
P ₁₄	23	24	P ₁₅
P ₁₆	25	26	P ₁₇
P ₁₈	27	28	P ₁₉
P ₂₀	29	30	P ₂₁
P ₂₂	31	32	P ₂₃
P ₂₄	33	34	P ₂₅
SHFCLK	35	36	FLM
M	37	38	LP
GND	39	40	ENABKL
P ₂₆	41	42	P ₂₇
P ₂₈	43	44	P ₂₉
P ₃₀	45	46	P ₃₁
P ₃₂	47	48	P ₃₃
P ₃₄	49	50	P ₃₅

*PVcc default +5V

Flat Panel Display interface

HS-XXX X	PIN #	Pin Name	Mono	Mono	Mono	Color	Color	Color	Color	Color	Color	Color	Color	Color	Color
			SS	DD	DD	TFT	TFT	TFT	TFT	STN-H R	STN-S S	STN-S S	STN-D D	STN-D D	STN-D D
			8-bit	8-bit	16-bit	9/12/16 bit	18 bit	18/24 bit	36-bit	18/24 bit	8-bit (4bP)	16-bit (4bP)	8-bit (4bP)	16-bit (4bP)	24-bit
9	P0	D0	UD3	UD7	B0		B0	FB0	FB0	R1	R1	UR1	UR0	UR0	
10	P1	D1	UD2	UD6	B1		B1	FB1	FB1	B1	G1	UG1	UG0	UG0	
11	P2	D2	UD1	UD5	B2	B0	B2	FB2	FB2	G2	B1	UB1	UB0	UB0	
12	P3	D3	UD0	UD4	B3	B1	B3	FB3	FB3	R3	R2	UR2	UR1	LR0	
13	P4	D4	UD3	UD3	B4	B2	B4	FB4	SB0	B3	G2	LR1	UR0	LG0	
14	P5	D5	UD2	UD2	G0	B3	B5	FB5	SB1	G4	B2	LG1	LG0	LB0	
15	P6	D6	UD1	UD1	G1	B4	B6	SB0	SB2	R5	R3	LB1	LB0	UR1	
16	P7	D7	UD0	UD0	G2	B5	B7	SB1	SB3	B5	G3	LR2	LR1	UG1	
17	P8			UD7	G3		G0	SB2	FG0		B3		UG1	UB1	
18	P9			UD6	G4		G1	SB3	FG1		R4		UB1	LR1	
19	P10			UD5	G5	G0	G2	SB4	FG2		G4		UR2	LG1	
20	P11			UD4	R0	G1	G3	SB5	FG3		B4		UG2	LB1	
21	P12			UD3	R1	G2	G4	FG0	SG0		R5		LG1	UR2	
22	P13			UD2	R2	G3	G5	FG1	SG1		G5		LB1	UG2	
23	P14			UD1	R3	G4	G6	FG2	SG2		B5		LR2	UB2	
24	P15			UD0	R4	G5	G7	FG3	SG3		R6		LG2	LR2	
25	P16						R0	FG4	FR0					LG2	
26	P17						R1	FG5	FR1					LB2	
27	P18					R0	R2	SG0	FR2					UR3	
28	P19					R1	R3	SG1	FR3					UG3	
29	P20					R2	R4	SG2	SR0					UB3	
30	P21					R3	R5	SG3	SR1					UR3	
31	P22					R4	R6	SG4	SR2					LG3	
32	P23					R5	R7	SG5	SR3					LB3	
33	P24							FR0							
34	P25							FR1							
41	P26							FR2							
42	P27							FR3							
43	P28							FR4							
44	P29							FR5							
45	P30							SR0							
46	P31							SR1							
47	P32							SR2							
48	P33							SR3							
49	P34							SR4							
50	P35							SR5							
35	SHFCLK: Pixel clock .Shift Clock														
36	FLM.VSYNC: First line marker														
37	DE,M: Panel AC driver control														
38	LP,HSYNC: Latch pulse														
40	ENABKL: Power sequencing control for enabling the backlight.(high active)														

R = RED G = GREEN B = BLUE F = FIRST S = SECOND U = UPER L = LOWER

3.13 IR Connector

The HS-6011 provides a 6-pin internal IR communication connector as following CN21 pin information.

☞ **CN21 : 6-PIN IR CONNECTOR**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	Vcc	4	GROUND
2	FIRRX	5	IRTX
3	IRRX	6	CVROFF

3.14 USB Port Connector

The HS-6011 provides a internal 8-pin header for two USB ports connection. Please refer to the following detail pin information.

☞ **CN20 : 8-pin Header USB Connector**

PIN NO.	CN20	PIN NO.	CN20
1	Vcc	2	Vcc
3	BD0-	4	BD1-
5	BD0+	6	BD1+
7	GROUND	8	GROUND

3.15 PC/104 Bus Connection

The HS-6011's PC/104 expansion bus provides you in connect to all kind of PC/104 modules. The PC/104 bus has been already become the industrial embedded 16-bit PC standard bus. You can easily install to over thousands type of PC/104 modules from hundreds of venders in the world. The detailed pin assignment of the PC/104 expansion bus connectors CN14 and CN15 are specified as following tables:

Note : The PC/104 connector allows to directly plug-in Stack-thru PC/104 modules without the PC/104 mounting kit.

CN14&CN15 : PC/104 Expansion Bus
(CN14 = 64-pin female connector; CN15 = 40-pin female connector.)

Pin No.	CN14 RowA	CN14 RowB	CN15 RowC	CN15 RowD
0	--	--	0V	0V
1	IOCHECK*	0V	SBHE*	MEMCS16*
2	SD7	RESETDRV	LA23	IOSC16*
3	SD6	+5V	LA22	IRQ10
4	SD5	IRQ9	LA21	IRQ11
5	SD4	-5V	LA20	IRQ12
6	SD3	DRQ2	LA19	IRQ15
7	SD2	-12V	LA18	IRQ14
8	SD1	NOWS*	LA17	DACK0*
9	SD0	+12V	MEMR*	DRQ0
10	IOCHRDY	(KEY)	MEMW*	DACK5*
11	AEN	SMEMW*	SD8	DRQ5
12	SA19	SMEMR*	SD9	DACK6*
13	SA18	IOW*	SD10	DRQ6
14	SA17	IOR*	SD11	DACK7*
15	SA16	DACK3*	SD12	DRQ7
16	SA15	DRQ3	SD13	+5V
17	SA14	DACK1*	SD14	MASTER*
18	SA13	DRQ1	SD15	0V
19	SA12	REFRESH*	(KEY)	0V
20	SA11	SYSCLK	--	--
21	SA10	IRQ7	--	--
22	SA9	IRQ6	--	--
23	SA8	IRQ5	--	--
24	SA7	IRQ4	--	--
25	SA6	IRQ3	--	--
26	SA5	DACK2*	--	--
27	SA4	TC	--	--
28	SA3	BALE	--	--
29	SA2	+5V	--	--
30	SA1	OSC	--	--
31	SA0	0V	--	--
32	0V	0V	--	--

3.16 Fast Ethernet Connector

The Fast Ethernet controller provides with 32-bit performance, PCI bus master capability, and full compliance with IEEE 802.3 10/100Based-T specifications.

For 10/100Base-T operation, please connect the network connection by plugging one end of the cable into the 9-pin RJ-45 CN22 Connector.

⚡ CN22 : Ethernet Connector (9-pin RJ-45)


PIN NO.	DESCRIPTION
1	TX+
2	TX-
3	RX+
4	NC
5	NC
6	RX-
7	NC
8	NC
9	Ground

For indication out the LAN operating status, the board provides three LED indicators in show out the status at follows:

- LE1: LED indicator lighting shows 10-Based data rating
- LE2: LED indicator lighting shows 100-Based data rating
- LE4: LED indicator lighting shows LAN in active

3.17 ATX Power Controller Connector

The HS-6011 support ATX Power function by CN11. The connector of CN11 can control the 5 pin ATX Power via the extension cable from the Backplane (from the version 6.1).



Chapter-4

AWARD BIOS Setup

The HS-6011 uses the Award PCI/ISA BIOS for the system configuration. The Award BIOS setup program is designed to provide the maximum flexibility in configuring the system by offering various options which could be selected for end-user requirements. This chapter is written to assist you in the proper usage of these features.

To access AWARD PCI/ISA BIOS Setup program, press key. The Main Menu will be displayed at this time.

4.1 Main Menu

Once you enter the Award BIOS CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to select among the items and press <Enter> to enter the sub-menu.

```
ROM PCI/ISA BIOS (2A69KD2C)
CMOS SETUP UTILITY
AWARD SOFTWARE, INC.
```

STANDARD CMOS SETUP	INTEGRATED PERIPHERALS
BIOS FEATURES SETUP	SUPERVISOR PASSWORD
CHIPSET FEATURES SETUP	USER PASSWORD
POWER MANAGEMENT SETUP	IDE HDD AUTO DETECTION
PNP/PCI CONFIGURATION	SAVE & EXIT SETUP
LOAD BIOS DEFAULTS	EXIT WITHOUT SAVING
LOAD SETUP DEFAULTS	
Esc : Quit	↑ ↓ → ← : Select Item
F10 : Save & Exit Setup	<Shift>F2 : Change Color

Note that a brief description of each highlighted selection appears at the bottom of the screen.

4.2 Standard CMOS Setup

The Standard Setup is used for the basic hardware system configuration. The main function is for Data/Time and Floppy/Hard Disk Drive settings. Please refer to the following screen for the setup. When the IDE hard disk drive you are using is larger than 528MB, please set the HDD mode to **LBA** mode. Please use the IDE Setup Utility in BIOS SETUP to install the HDD correctly.

ROM PCI / ISA BIOS <2A69KD2C>
 STANDARD CMOS SETUP
 AWARD SOFTWARE, INC.

Data (mm:dd:yy) : Tue, Jul 13 1999																				
Time (hh:mm:ss) : 15 : 3 : 6																				
HARD DISKS	TYPE	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE												
Primary Master	: Auto	0	0	0	0	0	0	AUTO												
Primary Slave	: Auto	0	0	0	0	0	0	AUTO												
Secondary Master	: Auto	0	0	0	0	0	0	AUTO												
Secondary Slave	: Auto	0	0	0	0	0	0	AUTO												
Drive A	: 1.44M, 3.5 in																			
Drive B	: None																			
LCD&CRT	: Auto																			
Halt On	: All Errors																			
					<table border="1"> <tr> <td>Base Memory</td> <td>:</td> <td>640k</td> </tr> <tr> <td>Extended Memory</td> <td>:</td> <td>3174k</td> </tr> <tr> <td>Other Memory</td> <td>:</td> <td>384k</td> </tr> <tr> <td>Total Memory</td> <td>:</td> <td>32768k</td> </tr> </table>				Base Memory	:	640k	Extended Memory	:	3174k	Other Memory	:	384k	Total Memory	:	32768k
Base Memory	:	640k																		
Extended Memory	:	3174k																		
Other Memory	:	384k																		
Total Memory	:	32768k																		
ESC : Quit			←←← : Select Item			PU/PD/+/- : Modify														
F1 : Help			(Shift) F2 : Change Color																	

4.3 BIOS Features Setup

This section allows you to configure your system for the basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing and security.

ROM PCI / ISA BIOS <2A69KD2C>
 BIOS FEATURES SETUP
 AWARD SOFTWARE, INC.

Virus Warning	: Disabled	Video BIOS	Shadow	: Enabled
CPU Internal Cache	: Enabled	C8000-CBFFF	Shadow	: Disabled
External Cache	: Enabled	CC000-CFFF	Shadow	: Disabled
CPU L2 Cache ECC Checking	: Enabled	D0000-D3FFF	Shadow	: Disabled
Quick Power On Self Test	: Disabled	D4000-D7FFF	Shadow	: Disabled
Boot Sequence	: A,C,SCSI	D8000-DBFFF	Shadow	: Disabled
Swap Floppy Drive	: Disabled	DC000-DFFFF	Shadow	: Disabled
Boot Up Floppy Seek	: Enabled			
Boot Up NumLock Status	: On			
Gate A20 Option	: Fast			
Typematic Rate Setting	: Disabled			
Typematic Rate (Chars/Sec)	: 6			
Typematic Delay (Msec)	: 250			
Security Option	: Setup			
PS/2 mouse function control	: Enabled			
PCI/VGA Palette Snoop	: Disabled			
OS Select For DRAM > 64MB	: Non-OS2	ESC	: Quit	←←←: Select Item
Report No FDD For WIN 95	: Yes	F1	: Help	PU / PD / +/- : Modify
		F5	: Old Values	(Shift) F2 : Color
		G6	: Load BIOS Defaults	
		G7	: Load Setup Defaults	

4.4 Chipset Features Setup

This section allows you to configure the system based on the specific features of the installed chipset. This chipset manages bus speeds and the access to the system memory resources, such as DRAM and the external cache. It also coordinates the communications between the conventional ISA and PCI buses. It must be stated that these items should never be altered. The default settings have been chosen because they provide the best operating conditions for your system. You might consider and make any changes only if you discover that the data has been lost while using your system.

ROM PCI / ISA BIOS <2A69KD2C>
 CHIPSET FEATURES SETUP
 AWARD SOFTWARE, INC.

Auto Configuration	: Enabled	Auto Detect DIMM/PCI Clk	: Enabled
EDO DRAM Speed Selection	: 60ns	Spread Spectrum	: Disabled
EDO CASx# MA Wait State	: 2	CPU Host Clock	: Default
EDO RASx# Wait State	: 2	CPU Warning Temperature	: Disabled
SDRAM RAS-to-CAS Delay	: 3	Current CPU Temperature	: 35°C / 95°F
SDRAM RAS Precharge Time	: 3		
SDRAM CAS latency Time	: 3		
SDRAM Precharge Control	: Disabled		
DRAM Date Integrity Mode	: Non-ECC		
System BIOS Cacheable	: Enabled		
Video BIOS Cacheable	: Enabled		
Video RAM Cacheable	: Enabled		
8 Bit I/O Recovery	: 1		
16 Bit I/O Recovery	: 1		
Memory Hole At 15M-16M	: Disabled		
Passive Release	: Disabled	ESC : Quit	←←←← : Select Item
Delayed Transation	: Enabled	F1 : Help	PU/PD/+/- : Modify
AGP Aperture Size	: 64	F5 : Old Values	(Shift) F2 : Color
		F6 : Load BIOS Defaults	
		F7 : Load Setup Defaults	

4.5 Integrated Peripherals

The IDE hard drive controllers can support up to two separate hard drives. These drives have a master/slave relationship which is determined by the cabling configuration used to attach them to the controller. Your system supports two IDE controllers--a primary and a secondary--so you can install up to four separate hard disks.

PIO means Programmed Input /Output. Rather than having the BIOS issue a series of commands to affect the transfer to or from the disk drive, PIO allows the BIOS to tell the controller what it wants and then let the controller and the CPU perform the complete task by them. This is much simpler and more efficient (also faster).

ROM PCI / ISA BIOS <2A69KD2C>
INTEGRATED PERIPHERALS
AWARD SOFTWARE, INC.

IDE HDD Block Mode	: Enabled	Onboard Parallel Port	: 378 / IRQ7
IDE Primary Master PIO	: Auto	Parallel Port Mode	: SPP
IDE Primary Slave PIO	: Auto		
IDE Primary Master PIO	: Auto		
IDE Primary Slave PIO	: Auto		
IDE Primary Master UDMA	: Auto		
IDE Primary Slave UDMA	: Auto		
IDE Primary Master UDMA	: Auto		
IDE Primary Slave UDMA	: Auto	LCD Panel Type	: Panel 5
On-Chip Primary PCI IDE	: Enabled		
On-Chip Secondary PCI IDE	: Enabled		
USB Keyboard Support	: Disabled		
Init Display First	: PCI Slot		
KBC input clock	: 8MHz	ESC	: Quit <i>Esc Esc Esc</i> : Select Item
Onboard FDC Controller	: Enabled	F1	: Help PU/PD/+/- : Modify
Onboard Serial Port 1	: 3F8/IRQ4	F5	: Old Values (Shift) F2 : Color
Onboard Serial Port 2	: 2F8/IRQ3	F6	: Load BIOS Defaults
UART Mode Select	: Normal	F7	: Load Setup Defaults

4.6 Power Management Setup

The Power Management Setup allows user to configure the system for saving energy in a most effective way while operating in a manner consistent with his own style of computer use.

ROM PCI-ISA BIOS <2A69KD2C>
POWER MANAGEMENT SETUP
AWARD SOFTWARE, INC.

Power Management	: User Define	** Reload Global Timer Events **
PM Control by APM	: Yes	IRQ3 [3-7, 9-15], NMI : Disabled
Video Off Method	: V/H SYNC + Blank	Primary IDE0 : Disabled
Video Off After	: Standby	Primary IDE1 : Disabled
MODEM Use IRQ	: 3	Secondary IDE 0 : Disabled
Doze Mode	: Disable	Secondary IDE 1 : Disabled
Standby Mode	: Disable	Floppy Disk : Disabled
Suspend Mode	: Disable	Serial Port : Enabled
HDD Power Down	: Disable	Parallel Port : Disabled
Throttle Duty Cycle	: 62.5%	
PCI/VGA Act-Monitor	: Disabled	
Power On by Ring	: Instant-Off	
CPU fan on temp high	: Enabled	
IRQ8 Break Suspend	: Disabled	
		ESC : Quit <<<<<< : Select Item
		F1 : Help PU/PD/+/- : Modify
		F5 : Old Values (Shift) F2 : Color
		F6 : Load BIOS Defaults
		F7 : Load Setup Defaults

